


# LCD FIREPLACE HEATER OWNER'S MANUAL

Three Sided LCD FIREPLACE

LCD38



**⚠ WARNING**

Read and understand this entire owner's manual including all safety information, before plugging in or using this product. Failure to do so could result in fire, electric shock, or serious personal injury.

**⚠ CAUTION**

Keep this owner's manual for future reference. If you sell or give this product away, make sure this manual accompanies this product.

# Contents

Parts and Hardware.....	4
Tools Required.....	4
Unpacking and Setup .....	4
Unpacking Instructions.....	4
BOX CONTENTS .....	4
Wiring.....	5
Testing the Fireplace Prior to Installation .....	5
Prong Outlet Installation .....	5
Power Data.....	5
Installation.....	6
WARNINGS.....	6
Choosing Installation Location .....	6
Choosing Wall Location.....	6
How to remove the glass panel bracket .....	6
Recessed Installation .....	7
Instructions:.....	7
Fire Dimensions.....	7
Recessed Installation Overview .....	8
Three-Sided Installation:.....	8
Two-Sided Installation: .....	8
Single-Sided Installation: .....	8
Partial Recess Installation: .....	8
Slide-in cabinet installation: .....	8
Recessed Installation .....	9
Installing the Crystal Ember and Log-set .....	10
Installing the Crystal Embers .....	10
Installing the Log-set .....	10
Reinstalling the Glass Panel .....	10
Operating Fireplace .....	11
Power .....	11
Methods of Operation.....	11
Control Panel.....	11
Wireless Remote Control.....	11
Method of Operation .....	12
Control Panel Functions .....	12
Method of Operation .....	13
Wireless Remote Control Functions .....	13
Remote Control Operation .....	14
Care and Maintenance .....	14
Cleaning.....	14
Maintenance.....	14
Wi-Fi Controls.....	15
Wi-Fi Controls.....	16
Wi-Fi Controls.....	17
Wi-Fi Controls.....	18
Bluetooth Controls.....	19
Warranty .....	20

# IMPORTANT SAFETY INFORMATION

## WARNING

- **THIS FIREPLACE IS HOT WHEN IN OPERATION AND CAN CAUSE SEVERE BURNS**
- Do not operate fireplace before reading and understanding operation instructions. Failure to operate fireplace according to operation instructions could cause fire or injury.
- Risk of burns. This fireplace is HOT when in operation and heating element is ON. Power to the fireplace should be turned off and the fireplace allowed to cool before servicing. To disconnect power to the fireplace, turn controls to off, then remove plug from outlet.
- Do not install damaged or incomplete, or substitute components.
- Young children should be carefully supervised when they are in same room with fireplace. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the house. To restrict access to the fireplace, install an adjustable safety gate to keep toddlers, young children and other at risk individuals away from the fireplace and hot surfaces.
- Clothing and other flammable material should not be placed on or near the fireplace.
- Due to high temperatures, the fireplace should be located out of traffic and away from furniture and draperies.
- Ensure that you have incorporated adequate safety measures to protect infants/toddlers from touching hot surfaces.
- It is imperative that the control compartments, circulating blower, and its passageway is kept clean.
- Under no circumstances should this fireplace be modified.
- Do not use the fireplace if any part has been under water.
- Do not operate the fireplace with the glass panel removed, cracked or broken.
- Keep the packaging material out of the reach of children. As with all plastic bags, these are not toys and should be kept away from children and infants.
- Servicing should only be done while the fireplace is disconnected from the power outlet.
- Unplug fireplace if not being used for an extended period of time.
- Do not operate this fireplace with a damaged cord or plug after the fireplace malfunctions, has been dropped, or damaged in any manner.
- Do not use outdoors.
- Never locate fireplace where it may fall into a bathtub or other water container.
- Do not run the cord under carpeting. Do not cover cord with throw rugs, runners, or the like. Arrange cord away from traffic area and where it will not be tripped over.
- Connect to properly grounded outlets only.
- Do not insert foreign objects into any ventilation or exhaust opening as this may cause an electric shock, fire, or damage to the fireplace.
- To prevent a possible fire, do not block the air intakes or exhaust in any manner. Do not use on soft surfaces, like a carpet, where openings may be blocked.
- Ensure clearances to combustibles are maintained when building a mantel or shelves above the fireplace. Elevated temperatures on the wall or in the air above the fireplace can cause melting, discoloration or damage to the decorations, a TV or other electronic components.

# Parts and Hardware

## Tools Required

- Phillips screwdriver
- Stud finder
- Level
- Tape measure
- Electric drill
- Wood drill bit










## Unpacking and Setup

### Unpacking Instructions

- Remove all parts and hardware from the carton and place them on a clean, soft, dry surface. Check the parts list to make sure no parts are missing. If parts are missing, please contact technical support for replacement parts.

**NOTE: Dispose of plastic bag, as it may cause choking hazard with young children. Do not let children play with plastic bag.**

### BOX CONTENTS

		
1 Fireplace		
		
Front Glass	2 Side Glass Pieces	1 Remote Control
		
Canyon Driftwood Logs	Crystal Embers	
		
2 Side Covers	Metal Bracket	Screws

# Wiring

The HM series recessed fireplace can be plugged into a grounded 3-prong outlet.

## Testing the Fireplace Prior to Installation

- Before installing the fireplace, test the fireplace to make sure that it operates properly. Due to the motor the fire will have a slight noise when in operation
- The remote will need syncing to the fire unit. This can be done in either of two ways.  
1: when plugging the fire in for the first time you need to use the remote rather than the buttons on the unit. When first plugged in you should see an orange light come on and whilst this is on you tap the red power button at the top of the remote several times and this will sync the remote. If the fire is already plugged in – you can unplug the fire, leave the fire off for 20 seconds and try the above again.

OR

2: When the fire is plugged in turn on the fire using the red button on the fire. Then whilst the fire is on hold down the red button on the unit for 3-4 seconds and this should bring the orange light on and then tap the red power button at the top of the remote several times to sync.

## Prong Outlet Installation

- Only use this fireplace on a 220V ac, 7.5-Amp grounded circuit. Never overload the circuit. If this fireplace trips the circuit breaker, unplug all other appliances on the same circuit before the next use. Avoid plugging other appliances into the same circuit as this fireplace.
- Always check the fireplace plug and connections before each use.
- Never plug this fireplace into an outlet that is cracked or has any loose wires or connections. Plugging this fireplace into a faulty outlet could result in the outlet overheating or catching fire.
- Make sure this plug fits securely into the outlet. Faulty wall outlet connections or loose plugs can cause the outlet to overheat. If the outlet or face plate is hot, discontinue use immediately and have a qualified electrician inspect and/or replace the faulty outlet.

## Power Data

<b>Model</b>	<b>LCD38</b>
<b>Voltage</b>	<b>220Vac</b>
<b>Watts</b>	<b>1500W</b>
<b>Amps</b>	<b>7.5AMP</b>

# Installation

## WARNINGS

- Due to high temperatures, keep the fireplace out of high traffic locations.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1M away from the front of the fireplace.
- Never install the fireplace where it may fall into a bathtub or other body of water.
- Wear safety gloves and safety glasses for protection during installation. Broken glass may cause injury or harm.
- Prevent contact with loose insulation. Do not install the fireplace against a vapor barrier or exposed insulation.
- Do not expose the fireplace to the elements (rain, etc).

## Choosing Installation Location

### Choosing Wall Location

- Measure wall location to ensure that fireplace will fit on desired wall location.
- Minimum clearances (measurements taken from front of glass panel):

<b>Bottom of Fireplace to Floor:</b> 150mm	<b>Top of Fireplace:</b> 200mm to mantel
<b>Sides of Fireplace:</b> 0mm	<b>Top of Fireplace:</b> 200mm to TV
<b>Back of Fireplace:</b> 0mm	<b>Top of Fireplace:</b> 200mm to ceiling

- Select a location that is not prone to moisture and is located at least 1000mm away from combustible materials such as curtains, drapes, furniture, bedding, or other combustible materials.
- See Safety Information for warnings about safe placement, safe installation, and proper use of this product.

## How to remove the glass panel bracket

1. Unscrew the metal strip on the top.
2. Lift the front glass up with sucker as Figure 2.1.
3. Take out the bottom of front glass.




Figure 2.1





Figure 2.2

## Recessed Installation

- Due to many different finish materials used on walls, it is highly recommended that you consult your local builder before you install this fireplace in the wall.
- Select a location that is not prone to moisture and is located at least 1000mm away from combustible materials such as curtains, drapes, furniture, bedding, or other combustible materials.
- In order to avoid the possibility of exposed insulation or vapor barrier coming in contact with the fireplace, it is recommended that the walls of the fireplace enclosure be “finished” (ie. Sheetrock, drywall, etc) as you would finish any other outside wall of your home. This will ensure that clearance to combustibles is maintained within the wall cavity.
- Never install fireplace into load-bearing walls. When recessing fireplace in a wall, recess into non-load bearing walls ONLY!

### Instructions:

1. Choose a location in the wall to install fireplace.
2. Make an opening in the wall based on metal firebox size.








### Fire Dimensions

Model	LCD38
Fireplace Height Overall	480mm
Fireplace Height Recess	480mm
Fireplace Width Overall	989mm
Fireplace Width Recess	963mm
Fireplace Depth Overall	235mm
Fireplace Depth Recess	224mm

## Recessed Installation Overview

The HM three-sided Electric Fireplace can be installed in five different recessed configurations:




 A perspective diagram showing a fireplace unit fully recessed into a wall. The top, bottom, and back surfaces are flush with the wall, while the front and side surfaces are exposed.	<p><b>Three-Sided Installation:</b></p> <ul style="list-style-type: none"><li>• Glass exposed on the left, front, and right sides</li><li>• Fireplace is fully recessed into the wall with both sides open</li></ul>
 A perspective diagram showing a fireplace unit recessed into a wall. The top, bottom, and back surfaces are flush with the wall. One side is fully recessed, while the front and the opposite side are exposed.	<p><b>Two-Sided Installation:</b></p> <ul style="list-style-type: none"><li>• Glass exposed on the front and left or right side.</li><li>• Fireplace is fully recessed into the wall with one side open.</li></ul>
 A perspective diagram showing a fireplace unit recessed into a wall. The top, bottom, and back surfaces are flush with the wall. Only the front surface is exposed, while both sides are fully recessed.	<p><b>Single-Sided Installation:</b></p> <ul style="list-style-type: none"><li>• Glass exposed in the front of the fireplace.</li><li>• Fireplace is fully recessed into the wall.</li></ul>
 A perspective diagram showing a fireplace unit partially recessed into a wall. The top, bottom, and back surfaces are flush with the wall. The front and both sides are exposed.	<p><b>Partial Recess Installation:</b></p> <ul style="list-style-type: none"><li>• Glass exposed on the left, front, and right sides</li><li>• Fireplace is fully recessed into the wall with both sides open</li></ul>
 A perspective diagram showing a fireplace unit installed within a cabinet. The top, bottom, and back surfaces are flush with the cabinet's interior. The front and both sides are exposed.	<p><b>Slide-in cabinet installation:</b></p> <ul style="list-style-type: none"><li>• Glass exposed on the left, front, and right sides</li><li>• Fireplace is fully recessed into the wall with both sides open</li></ul>



# Recessed Installation




## Three-Sided Installation:

1. Prepare the framed opening according to the Rough Opening Dimensions chart. Provide a 230Vac 7.5amp circuit for wire install at the top right of the framed opening.
2. Install Metal Bracket.
3. Install the fire unit in the framed opening with a minimum 1 ¼ drywall screws to secure the unit.
4. Mask the exposed fire unit during the drywall process. Install drywall to the drywall stops on the perimeter of the fire box.






## Two-Sided Installation:

1. Follow steps 1 & 2 from the three-sided installation instructions.
2. Remove the corresponding drywall stops according to your installation (in the example, the drywall stops on the left end would be removed.)
3. Install the side glass then the corresponding side cover according to your installation (the side glass must be installed before the metal side cover.)
4. Install the fire unit in the framed opening with a
5. minimum 1 ¼ drywall screws to secure the unit.
6. Mask the exposed fire unit during the drywall process. Install drywall to the drywall stops on the perimeter of the fire box.




## Single-Sided Installation:

1. Follow steps 1 & 2 from the three-sided installation instructions.
2. Remove the drywall stops on both sides of the fire unit.
3. Install the side glass then side covers on both sides of the fire unit.
4. Install the fire unit in the framed opening with a minimum 1 ¼ drywall screws to secure the unit.




### Partial Recess Installation (Optional):

Follow the directions included with the Partial Recess.



### Slide-in cabinet installation (Optional):

Follow the directions included with the Slide-in Cabinet.



## Installing the Crystal Ember and Log-set

Once the fireplace is installed in the wall, place crystal media stones and artificial logs in the fireplace.

### Installing the Crystal Embers

1. Carefully place crystal embers on plastic strip. Apply an even layer from side to side. Randomly place the crystals on top of the crystals to add an extra dimension to the ember bed.

### Installing the Log-set

1. Carefully place the log set in the designed ember slot.

## 2. Reinstalling the Glass Panel

3. Once completed installing crystal embers or fire log, you are now ready to reinstall the glass panel.

1. The unit has 2 channels on the top and bottom to hold the front glass.
2. Using the included suction cups, insert the glass at an angle in to the top channel.
3. Swing the bottom edge of the front glass in to the unit. See Figure 2.1.
4. Slide the glass down in to the bottom channel. See Figure 2.2
5. Fix the top metal strip by screws.




Figure 2.1




Figure 2.2

Your LCD Series fireplace is now ready for use!

# Operating Fireplace

Once the fireplace has been plugged into a grounded outlet, the fireplace is now ready for operation. Ensure that the house circuit breakers for the power supply are turned on.


## Power

Plug the power cable into a 220v 7.5 amp grounded outlet. Make sure the outlet is in good condition and that the plug is not loose. **NEVER** exceed the maximum amperage for the circuit. **DO NOT** plug other appliances into the same circuit.


## Methods of Operation

This electric fireplace can be operated by the CONTROL PANEL, located in the upper right hand corner of the fireplace, or by the WIRELESS REMOTE CONTROL. The operation and functions of both methods are the same.

### Control Panel








### Wireless Remote Control















# Method of Operation


## Control Panel Functions

BUTTON	FUNCTION	ACTION & INDICATION
 <p><b>POWER</b></p>	<p><b>ON:</b> Enables control panel functions and remote control. Turns on flame effect.</p> <p><b>OFF:</b> Disables control panel functions and remote control. Turns off flame effect.</p>	<ol style="list-style-type: none"> <li><b>Press once.</b> Indicator light turns on. Power turns on. All functions enabled.</li> <li><b>Press again.</b> Flame effect turns off. Unit goes to standby. All functions turn off.</li> </ol>
 <p><b>FLAME BRIGHTNESS</b></p>	<p><b>Dimmer button:</b> Each press of the button makes fuel bed dimmer and brighter.</p> <p><b>NOTE:</b> Dimmer effect stays on until power button is turned off.</p>	<ol style="list-style-type: none"> <li><b>Press once</b> to change the fuel bed brightness.</li> <li><b>Press again</b> until desired brightness setting is reached.</li> </ol>
 <p><b>FLAME COLOR</b></p>	<p><b>Flame Color button:</b> Changes the color flame effect.</p> <p><b>NOTE:</b> Flame effect stays on until power button is turned off.</p>	<ol style="list-style-type: none"> <li><b>Press once</b> to change the flame effect.</li> <li>It supports USB drive, you could add more flame effects by USB interface.</li> </ol>
 <p><b>HEATER</b></p>	<p><b>Heater button:</b> Turns heater on and off.</p> <p><b>NOTE:</b> To prevent overheating, the heater blows cool air for 30 seconds after it turns off.</p>	<ol style="list-style-type: none"> <li><b>Press once.</b> it shows "Low" on screen. Low heater turns on and blows warm air.</li> <li><b>Press again.</b> it shows "High" on screen. High heater turns on and blows hot air.</li> <li><b>Press again.</b> it shows "Close" on screen. The fan blows cool air for 30 seconds and then turns off.</li> </ol>
 <p><b>RESET</b></p>	<p><b>Reset button:</b> Reset to default state.</p>	<ol style="list-style-type: none"> <li><b>Press 3S.</b> Reset to default state.</li> </ol>

# Method of Operation

## Wireless Remote Control Functions

	Power button	Turn ON/OFF the fireplace
	Color ring	Global or single group color adjustable, short press the up and down keys to select among 8 colors, long press the up and down keys to select among 64 colors
	adjust	Used for adjusting functions such as time, week, temperature, etc. under different functions
	Dimmer	Adjustable brightness of global or single group LED
	Flame selection button	After selection, it's allowed to adjust the color and brightness of master flame.
	Ambient Light selection button	After selection, it's allowed to adjust the LED color and brightness of the downlightings.
	Ember bed light selection button	After selection, it's allowed to adjust the LED color and brightness of ember bed
	Mode button	Adjustable global or single group light flashing mode
	Timer button	When the remote control is turned off, short press to turn the weekly timer on or off, and long press to enter the weekly timer setting.  When the remote control is turned on, short press to enter the 0-8 hour timer setting, and long press to enter the week and time setting.
	Heater	Heater switch low-high-off continuous cycle
	Sound button	Crackle sound ON/OFF
	Reset	Reset to default state



### Notice: Additional instructions for weekly timer and clock settings

When the remote control is turned off, short press the clock button to turn the weekly timer on and off. Long press for 3 seconds to enter the weekly timer setting. Use the +/- key to select the day of the week and time. The clock key is the confirmation key. After each setting is completed, press the clock key to automatically enter the next setting. When selecting a day of the week when setting the weekly timer, the corresponding week icon will flash. Fast flashing means selected, slow flashing means unselected or canceled. The reset key is to return to the previous step. After each setting, it will automatically enter the next group of settings. The weekly timer can be set to 0-9 for a total of 10 groups. After the setting is completed, short press the power button to exit and save or wait for 10 seconds to automatically exit and save.

When the remote control is powered on, short press the clock button to enter the 0-8 hour timer setting. Use the +/- key to adjust. The clock key is the confirmation key. After the setting is completed, short press the clock key to exit and save or wait for 5 seconds to automatically exit and save. Long press for 3 seconds to enter the week and time settings. Use the +/- key to adjust the day of the week and time. The clock key is the confirmation key. After the setting is completed, short press the clock key to exit and save or wait for 10 seconds to automatically exit and save.

### Heating Notice:

Press heater button on remote, there will be flashing temperature which is your setting temperature, press "+" or "-" to set idea temperature.

The still temperature is room temperature that detected by fireplace and show up in remote screen. The temperature setting range is 50°F-86°F ( 10°C-30°C ), your setting temperature should be higher than room temperature, then heater will work normally. For example, if room temperature is lower than 50°F, there is no need to set up temperature, the heater will work. If the room temperature is over 86°F, the heater will not work. If the room temperature is among 50°F-86°F , the setting temperature must be higher than your room temperature, then heater will work.

## Remote Control Operation

- This remote control uses 2 AAA batteries
- To improve operation of the remote control, aim the remote control at the front of the fireplace. **DO NOT PRESS the buttons too quickly.** Give the unit time to respond to each command.
- **NOTICE: NEVER** dispose of batteries in fire. Failure to observe this precaution **may result in an explosion.** Dispose of batteries at your local hazardous material processing center.

## Care and Maintenance

### Cleaning

- **ALWAYS** turn the heater **OFF** and unplug the power cord from the outlet before cleaning, performing maintenance, or moving the fireplace. Failure to do so could result in electric shock, fire, or personal injury.
- **NEVER** immerse in water or spray with water. Doing so could result in electric shock, fire, or personal injury.

#### Metal:

- Buff using a soft cloth, slightly dampened with citrus oil-based product.
- **DO NOT** use brass polish or household cleaners, as these products will damage the metal trim.

#### Glass:

- Use a good quality glass cleaner sprayed onto a cloth or towel. Dry thoroughly with a paper towel or lint-free cloth.
- **NEVER** use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

#### Vents:

- Use a vacuum or duster to remove dust and dirt from the heater and vent areas.

#### Plastic:

- Wipe gently with a slightly damp cloth and a mild solution of dish soap and warm water.
- **NEVER** use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

## Maintenance

- **RISK OF ELECTRIC SHOCK! DO NOT OPEN any panels. No user-serviceable parts inside!**
- **ALWAYS** turn the heater **OFF** and unplug the power cord from the outlet before cleaning, performing maintenance, or moving the fireplace. Failure to do so could result in electric shock, fire, or personal injury.

#### Electrical and Moving Parts:

- The fan motors are lubricated at the factory and will not require lubrication.
- Electrical components are integrated in the fireplace and are not serviceable by the customer.

#### Storage:

- Store fireplace in a clean, dry place when not in use.

# Wi-Fi Controls

This fireplace is also capable of being controlled over Wi-Fi using an Apple or Android mobile device. Scan the QR code for an instructional walk through video on how to download and setup the app needed to control your Electric fireplace. Alternatively, you can follow the steps below.



Figure 29: QR Code for downloading Android/ iOS App





1. Download the app **Smart Life - Smart Living**, from either the Apple App Store or Google Play Store, and create a new user account.

2. Turn on the fireplace using either the control panel or remote control.

3. Navigate to the **Home** screen in the app and press the **Add Device** button.

4. On the Add Device screen select the **Small Home Appliances** category then pick **Electric Fireplace (Wi-Fi)**.



# Wi-Fi Controls

5. Next you will be prompted to connect to your existing home wireless network. Select the appropriate 2.4GHz network and log in.

**Note** - Only 2.4GHz wireless networks are compatible, 5GHz wireless networks cannot be used. If not available, contact your wireless service provider for further information on setting up a 2.4GHz wireless network.




Figure 32: Network Connection

6. Once you are connected to your home network put the fireplace into pairing mode. Press and hold the **COLOUR** button on the control panel (see page 14) of the fireplace until the back flame and ember bed begin flashing at the same time.

7. With the fireplace now in pairing mode select the **Blink Quickly** option on the **Reset the Device** screen in the app. The app will begin pairing to the fireplace on a timing screen and automatically finish once pairing is successful.




Figure 33: Fireplace Pairing





Figure 34: Fireplace Successfully Paired




# Wi-Fi Controls

8. With the fireplace now successfully paired it can be controlled in the same manner as the remote controls (see page 15). Added capabilities like Sleep Timer and Heat Program are only possible when using the app.



**Figure 35: Fireplace App Controls**


## Creating a Heat Program



**Figure 36: Heat Program - Step 1**

In the **My Ambiance** screen select the **Heat Program** option. This feature is a 7-day program that allows you to pick what time of day you would like the fireplace and heater to turn on and off.

1. Select the desired day of the week and time slot. In the example below a program has been selected for Wednesdays from 1:00PM-6:00PM.



**Figure 37: Heat Program - Step 2**

## Wi-Fi Controls

2. Next, in the pop-up window select the desired program settings:

**Switch** - Turn fireplace on or off

**Gear** - Turn heater on low, high, off

**Temperature** - Set desired temperature




Figure 38: Heat Program - Step 3

3. The Heat Program is now set to turn the fireplace and heater on at 1:00PM every Wednesday to maintain a temperature of 20°C until 6:00PM.




Figure 39: Heat Program - Step 4


# Bluetooth Controls

Also you could add fireplace into Smartlife APP by Bluetooth.

Firstly , power on fireplace, enable Bluetooth on your mobile phone;

Secondly, enter into Smartlife APP, the device will show up automatically , click "Add"

Finally, it will jump to WiFi information page, then click "Next" to finish adding device.




Devices to be added: 1



SD-Fireplace

Add



Next

## Warranty

Our electric fireplaces are to be free of defects in material and workmanship for one year from the date of purchase. This warranty only covers manufacturing faults.

This warranty does not cover damages, accidents, lack of maintenance, abuse or neglect. The warranty does not cover paint scratches, cosmetic blemishes, dents, corrosion or other normal wear and tear associated with the fireplace. Damage to the fire or other components due to water, weather damage, long periods of dampness or condensation. Damaging chemicals or cleaners are not covered under warranty.

This warranty does not cover breakage of the fireplace glass panel.

Affix Serial Number Label Here