

# Branch pipe

R410A: TAU335 TAU506 TAU730 TAU1350 TAU2040

unit:mm, ID: inner diameter; OD: outer diameter

	Gas side branch pipe	Liquid side branch pipe	Gas side manifold pipe	Liquid side manifold pipe
TAU335				
TAU506				
TAU730				
TAU1350				
TAU2040				

- Note:
1. The diameter of pipe between the first branch pipe and outdoor unit should be identical with the main pipe of outdoor unit.
  2. The diameter of pipe between branch pipe and indoor unit should be identical with the main pipe of indoor unit.
  3. The diameter adjustment of pipe between branch pipe and machine should be proceeded at the branch pipe side.
  4. Branch pipe(gas/liquid side) must be installed in horizontal or vertical direction.
  5. When welding the pipe, please must blow nitrogen. If not, a number of oxide will be produced and cause heavy damage.

