



AW-HKD018-N91 - 7SP023137

| P os. | Part No. | Description | Quant. | U n it | Stock dispo | | Matching 2 | Matching 3 |
|----------|--------------------|--------------------|--------|--------|-------------|---|------------|------------|
| 1 | 1PR190077 | Panel | 1 | | 0 | 0 | | |
| 2 | 1PR120101 | Air filter | 2 | | 0 | 0 | | |
| 3 | 17222000A 52734 | Display Board Assy | 1 | | 0 | 0 | | |
| 3.1 | 1PR030495 | Display board | 1 | | 0 | 0 | | |
| 4 | 121220000 13131 | Cover | 1 | | 0 | 0 | | |
| 5 | 1PR190214 | (B-C) Pannel | 1 | | 0 | 0 | | |
| 5.1 | 1PR190970 | Screw cover | 2 | | 0 | 0 | | |
| 6 | 121220000 13175 | Panel | 1 | | 0 | 0 | | |
| 7 | 121220000 13141 | Cover | 1 | | 0 | 0 | | |
| 8 | 1PR110336 | Louver | 1 | | 0 | 0 | | |
| 9 | 1PR150351 | Evaporator | 1 | | 0 | 0 | | |
| 10 | 121220000 13176 | Fan motor cover | 1 | | 0 | 0 | | |
| 11 | 1PR060132 | Fan motor | 1 | | 0 | 0 | | |
| 12 | 1PR160499 | Support | 1 | | 0 | 0 | | |
| 13 | 1PR160474 | Bearing | 1 | | 0 | 0 | | |
| 14 | 1PR110254 | Turbine | 1 | | 0 | 0 | | |
| 16 | 1PR190453 | Panel | 1 | | 0 | 0 | | |
| 16 .1 | 1PR090011 | Louver motor | 1 | | 0 | 0 | | |
| 16 .3 | 1PR110335 | Louver | 1 | | 0 | 0 | | |
| 16 .4 | 121220000 13186 | Panel | 1 | | 0 | 0 | | |
| 17 | 121220000 13178 | Fixing support | 1 | | 0 | 0 | | |
| 18 | 1PR160165 | (B-C)Support | 1 | | 0 | 0 | | |
| 19 | 1PR030687 | Electronic board | 1 | | 0 | 0 | | |

AW-HKD018-N91 - 7SP023137

| P os. | Part No. | Description | Quant. | U n it | Stock dispo | | Matching 2 | Matching 3 |
|----------|--------------------|----------------------------------|--------|--------|-------------|---|------------|------------|
| 19 .4 | 171220000 40114 | Electronic board | 1 | | 0 | 0 | | |
| 19 .5 | 121220000 13001 | Cover | 1 | | 0 | 0 | | |
| 19 .6 | 1PR070149 | Temperature Sensor | 1 | | 0 | 0 | | |
| 19 .7 | 174004010 00094 | Terminal board | 1 | | 0 | 0 | | |
| 19 .9 | 1PR070067 | Temperature Sensor | 1 | | 0 | 0 | | |
| 20 | 121220000 13132 | Electronic board support | 1 | | 0 | 0 | | |
| 21 | 7ACEL1740 | Remote controller IR RC08C AW | 1 | | 0 | 0 | | |
| 22 | 126007010 00039 | Rubber | 1 | | 0 | 0 | | |
| 23 | 1PR160106 | condensate bend | 1 | | 0 | 0 | | |
| 29 | 1PR160464 | Condensate tube | 1 | | 0 | 0 | | |
| 40 | 1PR120038 | Air filter | 1 | | 0 | 0 | | |
| 40 | 1PR120010 | (CR)Air filter | 1 | | 0 | 0 | | |
| 42 | 155002090 00001 | Leakage detection valve | 1 | | 0 | 0 | | |
| 45 | 1PR160670 | Support | 1 | | 0 | 0 | | |
| 46 | 155004060 00016 | Flare nut | 1 | | 0 | 0 | | |
| 46 | 155004060 00012 | Flare nut | 1 | | 0 | 0 | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |