



AW-HKD024-N91 - 7SP023138

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
1	1PR190078	Panel	1		0	0		
2	1PR120103	Air filter	2		0	0		
3	17222000A 52734	Display Board Assy	1		0	0		
3.1	1PR030495	Display board	1		0	0		
4	121220000 13357	Cover	1		0	0		
5	1PR190454	Panel	1		0	0		
5.1	121220000 13355	Screw cover	2		0	0		
7	121220000 13350	Cover	1		0	0		
8	1PR110338	Louver	1		0	0		
9	1PR150354	Evaporator	1		0	0		
10	121220000 13349	Cover	1		0	0		
11	1PR060548	Fan motor	1		0	0		
12	1PR160499	Support	1		0	0		
13	1PR160474	Bearing	1		0	0		
14	1PR110005	Turbine	1		0	0		
16	1PR190455	Panel	1		0	0		
16 .1	1PR090036	Louver motor	1		0	0		
16 .3	1PR110337	Louver	3		0	0		
16 .4	121220000 13342	Panel	1		0	0		
17	121220000 13346	Fixing support	1		0	0		
18	1PR160654	Wall support	1		0	0		
19	1PR030685	Electronic board	1		0	0		
19 .4	171220000 40110	Electronic board	1		0	0		

AW-HKD024-N91 - 7SP023138

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
19.5	121220000 20046	Electrical box	1		0	0		
19.6	1PR070149	Temperature Sensor	1		0	0		
19.7	174004010 00006	Terminal board	1		0	0		
19.9	1PR070067	Temperature Sensor	1		0	0		
20	121220000 13356	Electronic board support	1		0	0		
21	7ACEL1740	Remote controller IR RC08C AW	1		0	0		
22	126007010 00039	Rubber	1		0	0		
23	1PR160106	condensate bend	1		0	0		
29	1PR160464	Condensate tube	1		0	0		
40	1PR120038	Air filter	1		0	0		
40	1PR120010	(CR)Air filter	1		0	0		
42	155002090 00002	Leakage detection valve	1		0	0		
45	1PR160670	Support	1		0	0		
46	155004060 00003	Flare nut	1		0	0		
46	155004060 00010	Flare nut	1		0	0		