



AWAU-YKD024-H11 - 7SP062877

| P os. | Part No. | Description | Quant. | U n it | Stock dispo | | Matching 2 | Matching 3 |
|----------|--------------------|-----------------------|--------|--------|-------------|---|------------|------------|
| 1 | 122220000 04782 | Terminal board | 1 | | 0 | 0 | | |
| 2 | 1PR190323 | Panel | 1 | | 0 | 0 | | |
| 3 | 1PR140124 | Reversing valve | 1 | | 0 | 0 | | |
| 3 | | Reversing valve assy | | | 0 | 0 | | |
| 3.1 | 1PR140135 | Service valve | 1 | | 0 | 0 | | |
| 3.2 | 1PR140124 | Reversing valve | 1 | | 0 | 0 | | |
| 4 | 1PR190122 | Grill | 1 | | 0 | 0 | | |
| 5 | 1PR030708 | Electronic board assy | 1 | | 0 | 0 | | |
| 5.2 | 122220000 04827 | Cover | 1 | | 0 | 0 | | |
| 5.3 | 1PR030463 | Electronic board | 1 | | 0 | 0 | | |
| 5.4 | 121220000 06856 | Electrical box | 1 | | 0 | 0 | | |
| 6 | 1PR190852 | Handle | 1 | | 0 | 0 | | |
| 7 | 1PR160596 | Support | 1 | | 0 | 0 | | |
| 8 | 1PR060136 | (CR)Fan motor | 1 | | 0 | 0 | | |
| 9 | 1PR190481 | Panel | 1 | | 0 | 0 | | |
| 11 | 1PR010139 | Compressor | 1 | | 0 | 0 | | |
| 12 | 1PR190482 | Panel | 1 | | 0 | 0 | | |
| 13 | 155004060 00003 | Flare nut | 1 | | 0 | 0 | | |
| 13 | 155004060 00010 | Flare nut | 1 | | 0 | 0 | | |
| 14 | 122220000 04784 | Panel | 1 | | 0 | 0 | | |
| 15 | 1PR150212 | (R)Condenser | 1 | | 0 | 0 | | |
| 16 | 1PR070072 | Temperature Sensor | 1 | | 0 | 0 | | |
| 17 | 1PR190001 | Chassy | 1 | | 0 | 0 | | |
| 17 .1 | 122220000 04786 | Chassy | 1 | | 0 | 0 | | |

AWAU-YKD024-H11 - 7SP062877

| P os. | Part No. | Description | Quant. | U n it | Stock dispo | | Matching 2 | Matching 3 |
|----------|--------------------|--------------------|--------|--------|-------------|---|------------|------------|
| 17 .2 | 122220000 04788 | Foot | 1 | | 0 | 0 | | |
| 18 | 174004010 00016 | Terminal board | 1 | | 0 | 0 | | |
| 19 | 154220000 04974 | Service valve assy | 1 | | 0 | 0 | | |
| 19 .1 | 1PR140078 | Service valve | 1 | | 0 | 0 | | |
| 19 .2 | 122220000 02571 | Support | 1 | | 0 | 0 | | |
| 20 | 1PR190483 | Panel | 1 | | 0 | 0 | | |
| 21 | 1PR190480 | Panel | 1 | | 0 | 0 | | |
| 23 | 1PR070053 | Temperature Sensor | 1 | | 0 | 0 | | |
| 24 | 1PR110198 | Fan | 1 | | 0 | 0 | | |
| 25 | 1PR100031 | Coil | 1 | | 0 | 0 | | |
| 26 | 1PR070061 | Temperature Sensor | 1 | | 0 | 0 | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |