



AWSI-HKD012-N11 - 7SP023131

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
1	1PR190076	Panel	1		0	0		
2	1PR120105	Air filter	2		0	0		
3	17222000A 52734	Display Board Assy	1		0	0		
3.1	1PR030495	Display board	1		0	0		
4	121220000 13131	Cover	1		0	0		
5	1PR190452	Panel	1		0	0		
5.1	1PR190970	Screw cover	2		0	0		
6	121220000 13140	Panel	1		0	0		
7	121220000 13141	Cover	1		0	0		
8	1PR110334	Louver	1		0	0		
9	1PR150353	Evaporator	1		0	0		
10	121220000 13129	Cover	1		0	0		
11	1PR060052	Fan motor	1		0	0		
12	1PR160499	Support	1		0	0		
13	1PR160474	Bearing	1		0	0		
14	1PR110253	Turbine	1		0	0		
16	1PR190451	Panel	1		0	0		
16 .1	1PR090011	Louver motor	1		0	0		
16 .3	1PR110333	Louver	1		0	0		
16 .4	121220000 13123	Panel	1		0	0		
17	121220000 13136	Fixing support	1		0	0		
18	1PR160653	Wall support	1		0	0		
19	1PR031344	Electronic board assy	1		0	0		

AWSI-HKD012-N11 - 7SP023131

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
19 .4	1PR030475	Electronic board	1		0	0		
19 .5	121220000 13001	Cover	1		0	0		
19 .6	1PR070491	Temperature sensor	1		0	0		
19 .7	174004010 00094	Terminal board	1		0	0		
19 .9	1PR070492	Temperature sensor	1		0	0		
20	121220000 13132	Electronic board support	1		0	0		
21	7ACEL1740	Remote controller IR RC08C AW	1		0	0		
22	126007010 00039	Rubber	1		0	0		
23	1PR160106	condensate bend	1		0	0		
29	1PR160464	Condensate tube	1		0	0		
40	1PR120038	Air filter	1		0	0		
40	1PR120010	(CR)Air filter	1		0	0		
42	155002090 00001	Leakage detection valve	1		0	0		
45	1PR160670	Support	1		0	0		
46	155004060 00010	Flare nut	1		0	0		
46	155004060 00016	Flare nut	1		0	0		