



**AWSI-HKD018-N11 - 7SP023132**

<b>P os.</b>	<b>Part No.</b>	<b>Description</b>	<b>Quant.</b>	<b>U n it</b>	<b>Stock dispo</b>		<b>Matching 2</b>	<b>Matching 3</b>
1	1PR190077	Panel	1		0	0		
2	1PR120101	Air filter	2		0	0		
3	17222000A 52734	Display Board Assy	1		0	0		
3.1	1PR030495	Display board	1		0	0		
4	121220000 13131	Cover	1		0	0		
5	1PR190214	(B-C) Pannel	1		0	0		
5.1	1PR190970	Screw cover	2		0	0		
6	121220000 13175	Panel	1		0	0		
7	121220000 13141	Cover	1		0	0		
8	1PR110336	Louver	1		0	0		
9	1PR150352	Evaporator	1		0	0		
10	121220000 13176	Fan motor cover	1		0	0		
11	1PR060132	Fan motor	1		0	0		
12	1PR160499	Support	1		0	0		
13	1PR160474	Bearing	1		0	0		
14	1PR110254	Turbine	1		0	0		
16	1PR190453	Panel	1		0	0		
16 .1	1PR090011	Louver motor	1		0	0		
16 .3	1PR110335	Louver	1		0	0		
16 .4	121220000 13186	Panel	1		0	0		
17	121220000 13178	Fixing support	1		0	0		
18	1PR160165	(B-C)Support	1		0	0		
19	1PR031351	Electronic board assy	1		0	0		

**AWSI-HKD018-N11 - 7SP023132**

<b>P os.</b>	<b>Part No.</b>	<b>Description</b>	<b>Quant.</b>	<b>U n it</b>	<b>Stock dispo</b>		<b>Matching 2</b>	<b>Matching 3</b>
19 .4	171220000 39674	Electronic board	1		0	0		
19 .5	121220000 13001	Cover	1		0	0		
19 .6	1PR070491	Temperature sensor	1		0	0		
19 .7	174004010 00094	Terminal board	1		0	0		
19 .9	1PR070492	Temperature sensor	1		0	0		
20	121220000 13132	Electronic board support	1		0	0		
21	7ACEL1740	Remote controller IR RC08C AW	1		0	0		
22	126007010 00039	Rubber	1		0	0		
23	1PR160106	condensate bend	1		0	0		
29	1PR160464	Condensate tube	1		0	0		
40	1PR120038	Air filter	1		0	0		
40	1PR120010	(CR)Air filter	1		0	0		
42	155002090 00001	Leakage detection valve	1		0	0		
45	1PR160670	Support	1		0	0		
46	155004060 00016	Flare nut	1		0	0		
46	155004060 00012	Flare nut	1		0	0		