



AW-HDM018-N91 - 7SP023092

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
	1PR120148	Air filter			0	0		
	1PR120148	Air filter			0	0		
1	1PR190827	Panel	1		0	0		
2	1PR120145	Air filter	2		0	0		
3	HX001021 1702	Cover	3		0	0		
4	1PR190790	Panel	1		0	0		
5	1PR110309	Turbine	1		0	0		
6	1PR160799	Bearing	1		0	0		
7	1PR160578	Bearing support	1		0	0		
8	1PR110377	Louver	1		0	0		
9	HX001020 9723	Axe	3		0	0		
10	HX001020 9029	Louver	3		0	0		
11	1PR190814	Panel	1		0	0		
12	1PR160204	Plug	1		0	0		
13	HX001021 1698	Support	1		0	0		
14	HX001020 6934	Condensate tubing	1		0	0		
15	1PR160871	tubing fixing	1		0	0		
16	1PR160668	Wall support	1		0	0		
17	HX001020 9030	Support	1		0	0		
18	HX001020 7635	Support	1		0	0		
19	1PR150456	Evaporator	1		0	0		
20	HX001010 2525	Electrical box	1		0	0		
21	1PR160867	Electrical box cover	1		0	0		
22	1PR160866	Electrical box	1		0	0		

AW-HDM018-N91 - 7SP023092

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
23	1PR031248	Electronic board	1		0	0		
24	HX001040 3863	Terminal board	1		0	0		
25	HX001020 8734	Axe	1		0	0		
26	1PR090083	Louver motor	1		0	0		
27	1PR060575	Fan motor	1		0	0		
28	1PR160778	(CNR) Cover	1		0	0		
29	1PR160777	Cover	1		0	0		
30	1PR160772	Electrical box cover	1		0	0		
31	1PR160773	Cover	1		0	0		
32	HX001021 1703	Cover	1		0	0		
33	HX001021 1167	Support	1		0	0		
34	HX001021 1168	Support	1		0	0		
35	HX001087 7304	Cover	1		0	0		
36	HX001021 1048	(CNR) Electrical box	1		0	0		
37	1PR031243	Display board	1		0	0		
38	1PR070411	Temperature Sensor	1		0	0		
39	HX001A46 00001	Batteries	2		0	0		
40	7ACEL1758	Remote controller IR RC09	1		0	0		
41	HX001A14 34039A	Condensate tubing	1		0	0		
42	HX001060 0367B	Screws	2		0	0		
43	HX001A14 33307	Support	1		0	0		

AW-HDM018-N91 - 7SP023092

P os.	Part No.	Description	Quant.	U n it	Stock dispo		Matching 2	Matching 3
44	HX001021 1049	Electrical box	1		0	0		